


Usage of elder pitch to clean the diamond stylus





To clean the diamond, use only the cutting edge of the elder pitch.



Make sure that the contact surface of the elder pitch is cleaned from contaminations at all time.

Likewise, make sure that the “wooden” parts of the elder pitch never get in contact with the diamonds.



Freshly cut front part of the elder pitch has to be briefly dipped into acetone and is then ready to be used for cleaning the diamond.